



motorola Talkabout 2 Way Radios

MJ270R FRS/G...
2 channels, 1...
odes, 2662 c...

UPSDV 071
11220
965694 K B7D
\$47.99



up to
27
mile range*
under optimum
conditions



Mini-USB Port
for convenient
charging

MOTOROLA

MOTOROLA

Built-in Flashlight
Emergency light source.

Easy Charge***
Use desktop charger or mini-USB
port for convenient charging.

Emergency Alert Button
Used to send out distress call.

Dual Power
Works with alkaline or NiMH
rechargeable batteries.

motorola Talkabout® 2-Way Radios

MJ270
22 channels
codes 2662

CPS/FRSDV



071
11220
265694 K/B7D
\$47.99



up to
27
mile range*
under optimum
conditions



Mini-USB Port
for convenient
charging

motorola

Talkabout® 2-Way Radios

MJ270R



NOAA Weather Radio**

Receive weather alerts.



Emergency Preparedness

Perfect for the emergency preparation kit.



iVOX / VOX

Hands-free operation with or without accessories.



Quiet Talk

Eliminates interference from non-Motorola units.



Scan

Searches programmed list of channels and codes to find transmissions.



10 Call Tones

Individual tones allow you to alert others that you want to talk to them.



Talk Confirmation Tone

Transmitted tone to let the other person know you are finished talking.



Low Battery Alert


Reminder to replace or charge the batteries.



Keypad Lock

Allows you to avoid accidentally changing the operation of the radio.

*How far can I expect my radios to communicate? The communication range quoted is calculated under optimum conditions, with an unobstructed line of sight. Actual range will vary depending on terrain and conditions, and is often less than the maximum possible. Your actual range will be limited by several factors including, but not limited to, terrain, weather conditions, electromagnetic interference, and obstructions.



FRS/GMRS use approved in US and Canada only. GMRS license required in US.

***NiMH rechargeable battery packs included. Desktop charger included. Mini-USB car, wall and PC charging cables are sold separately.

Manufactured, distributed or sold by Giant International Ltd., official licensee for this product. Motorola, the Stylized M Logo, and other Motorola trademarks and trade dress are owned by Motorola, Inc. and are used under license from Motorola, Inc. MOTOROLA and the Stylized M Logo are registered in the US Patent & Trademark Office. All other product or service names are the property of their respective owners. ©Motorola, Inc. 2009. All rights reserved.

Please contact customer service at 800-638-5119 or e-mail us at giantintl@callcenter.com for questions/comments, warranty, support or service related to this product.

**NOAA radio service may not be available in all areas. Check with your local weather office for frequency and details, or visit www.weather.gov/nwr, (Canada: www.msc.ec.gc.ca/msb/weatherradio).

KEM-PK29900-02A



Motorola uses environmentally conscious designs which restricts the use of certain chemicals and ensures we meet European RoHS requirements. These product designs include the use of lead-free solder.

motorola.com



motorola Talkabout® 2-Way Radios

MJ270R FRS/GMRS radios
22 channels, 121 privacy
codes, 2662 combinations



Built-in Flashlight

Emergency light source.



Easy Charge***

Use desktop charger or mini-USB port for convenient charging.



Emergency Alert Button

Used to send out distress call.



Dual Power

Works with alkaline or NiMH rechargeable batteries.

GU5134A



MJ270 RECHARGEABLE

MODEL NUMBER

MJ270R



Giant International Ltd., Atlanta, GA 30305

UPC #



8 43677 00007 8

21-124

MADE IN CHINA

WARNING

CHOKING HAZARD - SMALL PARTS

Not intended for children under 3 yrs.

This product is not intended to be used as a toy or plaything.

KEM-PK29911-02A



KEBT-071-D 650mAh 1046

Must be recycled or disposed of properly. Recycling facilities may not exist in all areas.




NI-MH

STOP OTHER SIDE UP WHEN IN RADIO. DO NOT REMOVE LABEL.

CAUTION: To Prevent Injury See Manual. *Do not disassemble or unwrap.*
ATTENTION: Pour prévenir toute blessure, reportez-vous au Manuel. *Ne pas défaire ni déballer.*
PRECAUCION: Para prevenir daño vea el Manual. *No desensamble o desenvuelva.*
ATENÇÃO: Para prevenir danos veja o Manual do Usuário. *Não desmontar ou desembalar.*

3.6V NICKEL-METAL HYDRIDE BATTERY
BATTERIE AU NICKEL METAL HYDRURE DE 3.6V
3.6Vcc BATERIA DE HIDRURO DE METAL-NIQUEL
3.6V BATERIA DE NIQUEL METAL HIDRETO
MADE IN CHINA



LIFT HERE ↑

Works with alkaline or NiMH rechargeable batteries.


Dual Power

Emergency Alert Button

to send out distress call.




Giant I



Display Screen Guide

Numbers for Channel,
Call Tone

Numbers for Codes



— Battery Meter



— Channel Power Indicator (see Menu Options)



— Lock



— Talk Confirmation Tone (Roger Beep)

QT — Noise Filtering

ON — On/Off for each feature
OFF

— Scan



— Call Tone, Keypad Tone



— Weather Alert

iVOX — Hands-Free Use Without Accessories

VOX — Hands-Free Use With Accessories

Getting Started

Installing the Batteries

Each radio can use either 1 NiMH rechargeable battery pack or 3 AA alkaline batteries and beeps when the batteries are low.

Installing NiMH Rechargeable Battery Pack (Optional Accessory)

1. Turn the radio off.

Installing the Batteries

Each radio can use either 1 NiMH rechargeable battery pack or 3 AA alkaline batteries and beeps when the batteries are low.




Installing NiMH Rechargeable Battery Pack (Optional Accessory)

1. Turn the radio off.
2. With the back of the radio facing you, lift the battery cover latch up and remove the cover.
3. Remove the NiMH battery pack from the clear plastic bag (Do not disassemble or unwrap the battery pack).
4. Insert the NiMH battery pack with the diagram facing you.
5. Reposition the battery cover and press down to secure.

Installing the Three AA Alkaline Batteries

1. Turn the radio off.
2. With the back of the radio facing you, lift the battery cover latch up and remove the cover.
3. Insert the three AA alkaline batteries with + and - polarity as shown inside.
4. Reposition the battery cover and press down to secure.

Radio Battery Meter

The radio battery icon shows the battery charge level, from full  to empty . When the radio has one segment left, the radio chirps periodically or after releasing  (Low Battery Alert).


Removing the NiMH Battery Pack (Optional Accessory)

1. Turn the radio off.
2. With the back of the radio facing you, lift the battery latch up to release the battery cover and remove the cover.
3. Remove the NiMH battery pack by pulling the ribbon attached to the radio.
4. Reposition the battery cover and press down to secure.


Removing the Three AA Batteries

1. Turn the radio off.
2. With the back of the radio facing you, lift the battery latch up to release the battery cover and remove the cover.

Control Buttons



Display Screen Guide



Z — Scan

♪ — Call Tone, Keypad Tone

☁ — Weather Alert

iVOX — Hands-Free Use Without Accessories

VOX — Hands-Free Use With Accessories

Getting Started

3. Gently remove each alkaline battery by easing each battery out individually.
4. Reposition the battery cover and press down to secure.

Notes

- Exercise care when removing NiMH or AA batteries. Do not use sharp or conductive tools to remove either of these batteries.
- Remove the batteries before storing your radio for extended periods of time. Batteries corrode over time and may cause permanent damage to your radio.

Using the Battery Charger (Optional Accessory)

The battery charger provides drop-in charging convenience for NiMH batteries and can be placed on any flat surface, such as a desk or workbench. Charge the NiMH battery overnight (at least 16 hours) before using it for the first time. After the initial charge, an empty battery is fully charged within 14 hours.

1. Follow the steps above to install a NiMH Battery Pack.
2. Plug the AC power supply cord into the jack on the desk stand.
3. Plug the AC power supply into a standard wall outlet.
4. With a radio facing forward, slide it into one of the charging pockets.
5. When charging in the battery charger, the red light on the charger base will glow continuously.

Using the mini-USB Charging Connector

The mini-USB charging connector is a handy port that allows you to conveniently charge your NiMH battery pack. This is an alternative to charging your NiMH battery pack in the Battery Charger desk stand using the AC wall adaptor and especially useful when used while traveling.

Available mini-USB charging options: (optional accessories)

1. Wall travel charger
2. Vehicle charger
3. Mini-USB computer cable

If using a computer, the computer must be turned on.


This and other accessories (sold separately) are available for your radio. For more information, visit our Web site at www.motorola.com or shop.giantintl.com.


1. Plug your mini-USB cable or charger into a power source as is appropriate for your accessory.
2. Plug the cable into the mini-USB port on the bottom of your radio.
3. An empty battery will be fully charged in 14 hours.
4. The LED indicator light on the radio will glow to indicate that the battery is charging.


Notes


- The light will remain red after the NiMH battery pack is fully charged.
- When moving between hot and cold temperatures, do not charge the NiMH battery pack until the battery temperature acclimates (usually about 20 minutes).
- For optimal battery life, remove the radio from the charger within 16 hours. Do not store the radio while connected to the charger.
- If the radio is kept on while charging, the charging time will be extended.

Even though the charger is connected, you may not be able to

 — Battery Meter


 — Channel Power Indicator (see Menu Options)


 — Lock


 — Talk Confirmation Tone (Roger Beep)

QT — Noise Filtering

 ON — On/Off for each feature
 OFF

 — Scan

 — Call Tone, Keypad Tone

 — Weather Alert

iVOX — Hands-Free Use Without Accessories

VOX — Hands-Free Use With Accessories

Getting Started

Installing the Batteries

Each radio can use either 1 NiMH rechargeable battery pack or 3 AA alkaline batteries and beeps when the batteries are low.




Installing NiMH Rechargeable Battery Pack (Optional Accessory)

1. Turn the radio off.
2. With the back of the radio facing you, lift the battery cover latch up and remove the cover.
3. Remove the NiMH battery pack from the clear plastic bag (Do not disassemble or unwrap the battery pack).
4. Insert the NiMH battery pack with the diagram facing you.
5. Reposition the battery cover and press down to secure.

Installing the Three AA Alkaline Batteries

1. Turn the radio off.
2. With the back of the radio facing you, lift the battery cover latch up and remove the cover.
3. Insert the three AA alkaline batteries with + and - polarity as shown inside.
4. Reposition the battery cover and press down to secure.

Radio Battery Meter

The radio battery icon shows the battery charge level, from full  to empty . When the radio has one segment left, the radio chirps periodically or after releasing  (Low Battery Alert).

Removing the NiMH Battery Pack (Optional Accessory)

1. Turn the radio off.
2. With the back of the radio facing you, lift the battery latch up to release the battery cover and remove the cover.
3. Remove the NiMH battery pack by pulling the ribbon attached to the radio.
4. Reposition the battery cover and press down to secure.



Removing the Three AA Batteries

1. Turn the radio off.
2. With the back of the radio facing you, lift the battery latch up to release the battery cover and remove the cover.

If using a computer, the computer must be turned on. This and other accessories (sold separately) are available for your radio. For more information, visit our Web site at www.motorola.com or shop.giantintl.com.

1. Plug your mini-USB cable or charger into a power source as is appropriate for your accessory.
2. Plug the cable into the mini-USB port on the bottom of your radio.
3. An empty battery will be fully charged in 14 hours.
4. The LED indicator light on the radio will glow to indicate that the battery is charging.

Notes

- The light will remain red after the NiMH battery pack is fully charged.
- When moving between hot and cold temperatures, do not charge the NiMH battery pack until the battery temperature acclimates (usually about 20 minutes).
- For optimal battery life, remove the radio from the charger within 16 hours. Do not store the radio while connected to the charger.
- If the radio is kept on while charging, the charging time will be extended.
- Even though the charger is connected, you may not be able to transmit a message if the battery is completely empty . Allow time for the battery to charge to 1 bar  before attempting to transmit a message.


Attaching and Removing the Belt Clip

1. Attach belt clip to pocket or belt strap.
2. Align the belt clip post with the hole in the back of the radio.
3. Gently push until the clip clicks in place.

To Remove



1. Push down on the release tab at the top of the belt clip to release the catch.
2. Pull the belt clip away from the back of the radio.



Turning your Radio On and Off

Turn  clockwise to turn the radio on and counterclockwise to turn the radio off.

1. In the ON position, the radio chirps and briefly shows all feature icons available on the radio.
2. The display screen then shows the current channel, code and all features that are enabled.

Setting the Volume


Press and hold  for three seconds while rotating  until you reach a comfortable listening level.


1. Rotate  clockwise to increase the volume.
2. Rotate  counterclockwise to decrease the volume.

Do not hold the radio close to your ear. If the volume is set to an uncomfortable level, it could hurt your ear.

Talking and Listening

To communicate, all radios in your group must be set to the same channel and Interference Eliminator Code.

1. To talk, press and hold .



2. When you are finished talking, release .

For maximum clarity, hold the radio two to three inches away from your mouth and speak directly into the microphone. Do not cover the microphone while talking.


Talk Range

Your radio is designed to maximize performance and improve transmission range. Do not use the radios closer than five feet apart.

Monitor Button

Pressing and holding  for three seconds allows you to listen to the volume level of the radio when you are not receiving. This allows you to adjust the volume, if necessary. You can also press  to check for activity on the current channel before you talk.








Push to Talk Timeout Timer

To prevent accidental transmissions and save battery life, the radio emits a continuous warning tone and stops transmitting if you press  for 60 continuous seconds.

Menu Options

Selecting the Channel






Your radio has 22 channels. The channel is the frequency your radio uses to transmit. Channels 8-14 are FRS 0.5 watt only and all other channels are GMRS. (See the "Channels and Frequencies" table on overleaf for details.)



1. With the radio on, press . When the radio is on a 0.5 watt channel,  displays. When the radio is on a 1.5 watts channel,  displays. The current channel flashes.
2. Press  or  and select an unused or quiet channel.
3. Press  to save the channel setting or  to continue set up.

Selecting the Interference Eliminator Code

Interference Eliminator Codes help minimize interference by blocking transmissions from unknown sources. Your radio has 121 Interference Eliminator Codes. Codes 1 – 38 are the standard analog codes that appear on other FRS/GMRS radios. Codes 39 – 121 are additional digital codes added for superior interference protection. 0 is the off position, no analog or digital codes are enabled.

To set the code for a channel:






1. Press  until the code starts to flash.
2. Press  or  to select the code.
3. Press  to save the code setting or  to continue set up.



You can set a different code for each channel using this procedure. An extended press of  or  allows you to scroll through the Interference Code rapidly so you can quickly reach the code you want.

Note: You must set the Interference Eliminator Code to 0 on a radio that uses Interference Eliminator Codes to communicate with radio that do not have Interference Eliminator Codes. Select 0 for "no tone, no code" and OFF will flash on your radio's display.

Setting and Transmitting Call Tones

Your radio can transmit different call tones to other radios in your group so you can alert them that you want to talk. You have 10 call tones from which to choose.

1. Press  until the code starts to flash.
2. Press  or  to select the code.
3. Press  to save the code setting or  to continue set up.







You can set a different code for each channel using this procedure. An extended press of  or  allows you to scroll through the Interference Code rapidly so you can quickly reach the code you want.


Note: You must set the Interference Eliminator Code to 0 on a radio that uses Interference Eliminator Codes to communicate with radios that do not have Interference Eliminator Codes. Select 0 for "no tone, no code" and OFF will flash on your radio's display.

Setting and Transmitting Call Tones

Your radio can transmit different call tones to other radios in your group so you can alert them that you want to talk. You have 10 call tones from which to choose.

To set a call tone:






1. With the radio on, press  three times until the current call tone setting (0 - 10) flashes and  appears.
2. Press  or  to change and hear the call tone.
3. Press  to set the new call tone or  to continue set up.

To transmit your call tone to other radios set to the same channel and Interference Eliminator Code as your radio, press .

Note: Setting the call to 0 disables the call tone feature.

Hands-Free Use Without Accessories (iVOX)

You can use the iVOX feature to transmit hands-free without the need for any headset accessories. Once iVOX is turned on, the radio detects your voice and transmits when you speak into the internal microphone.

1. Press  until iVOX appears on the display. The current setting On/Off will flash.
2. Press  or  to select On or Off.
3. Press  to set or  to continue set up.


Hands-Free Use With Accessories (VOX)

You can transmit hands-free more reliably with the use of optional headset accessories. Once VOX is turned on, the radio detects your voice and transmits when you speak.

Many accessories (sold separately) are available for your radio. For more information, visit our Web site at www.motorola.com or shop.giantintl.com.

Turn the radio off and plug the VOX accessory into the accessory port.

Turn the radio on. VOX shows on the display.

Adjust the volume appropriately by rotating . Lower the volume before placing the accessory on your head or in your ear.

Continued on back

MJ Series

4. To turn off, simply remove the battery cover. **Note:** There is a short delay between the time you start talking and when the radio transmits. There is a short delay before the transmission is completed.

Setting the Sensitivity Level When in VOX or iVOX Mode

Adjusting the radio's sensitivity level helps minimize the possibility of unintended noises triggering a transmission and helps the radio pick up soft voices.

1. Press until VOX/iVOX and the level setting (1-3) appear on the display.
2. Press or to select the sensitivity level.
3. Press to set or to continue set up.

- | |
|--|
| 3 = High Sensitivity for quiet environments |
| 2 = Medium Sensitivity for most environments |
| 1 = Low Sensitivity for noisy environments |

Note: When you connect a headset, the radio is automatically set to the last chosen sensitivity level.

Q_T Noise Filtering

The Q_T noise-filtering feature helps to ensure uninterrupted communication with other Motorola radios that have this feature. This feature also filters out unwanted transmissions from other radios. This is useful in places where there is heavy radio traffic, such as amusement parks or ski resorts.

Note: Q_T noise filtering is not available when the radio is scanning.

To turn Q_T noise filtering on or off:

1. Press until QT displays. The current setting On/Off will flash.
2. Press or to turn noise filtering On or Off.
3. Press to confirm your selection or to continue set up.

To transmit to a radio that has Q_T noise filtering turned on:

1. Select the same channel and Interference Eliminator Code as the other radio.
2. Press to send a call tone. This allows your voice to pass through the Q_T noise filter on the receiving radio.
3. Press and speak normally.

Note: If you skip step 2, the beginning of your message may not be heard on the receiving radio. For a 30-second period, starting after the last transmission, all transmissions received on the selected channel and code will pass through the Q_T noise filter.

Keypad Tones

You may enable or disable the speaker key tones. You will hear the key tone each time a button is pushed.

1. Press until appears. The current setting On/Off will flash.
2. Press either or to turn On or Off.
3. Press to confirm or to continue set up.

Note: When the key tone feature is off, the following are not disabled:

- Transmit timeout alert tone
- Call tone
- Low battery alert tone or
- The transmitted talk confirmation tone

Transmitting a Talk Confirmation Tone

You can set your radio to transmit a unique tone when you finish transmitting. It is like saying "Roger" or "Over" to let others know you are finished talking.

1. With the radio on, press until the appears. The current setting On/Off flashes.
2. Press or to turn On or Off.
3. Press to set or to quit menu mode.

Eliminator Code. **Warning:** The Emergency Alert feature should only be used in response to an actual emergency. Motorola is not responsible if there is no response to the emergency alert from the receiving group.

Built-in Flashlight

Press and hold the flashlight button to turn and keep the light on. The switch functions as a momentary control for the light.

Note: Turn off the flashlight when not in use to conserve battery power.

Keypad Lock

To avoid accidentally changing your radio settings:

1. Press and hold until displays.
 2. When in lock mode, you can turn the radio on and off, adjust the volume, receive, transmit, send a call tone, and monitor channels. All other functions are locked.
- To unlock the radio, press and hold until is no longer displayed.

Scanning Channels

Use scan to search the 22 channels for transmissions from unknown parties, to find someone in your group who has accidentally changed channels, or to quickly find unused channels for your own use.

There is a priority feature and 2 modes of scanning (basic and advanced) to make your search more effective. The basic scan mode uses the channel and code combinations for each of the 22 channels as you have set them (or with the default code value of 1). The "Advanced Scan" mode will scan all channels for any and all codes, detect any code in use, and use that code value temporarily for that channel.

Priority is given to the "home channel," that is, the channel (and Interference Eliminator Code) your radio is set to when you start the scan. This means the initial channel (and code setting) is scanned more often than the other 21 channels, and your radio will respond quickly to any activity occurring on the home channel as a priority.

To start Scanning:

1. Briefly press the key. The scan will appear in the display, and the radio will begin to scroll through the channel and code combinations.
2. When the radio detects channel activity matching the channel and code combination, it stops scrolling and you can hear the transmission.
3. To respond and talk to the person transmitting, press within five seconds after the end of the transmission.
4. The radio will resume scrolling through the channels five seconds after the end of any received activity.
5. To stop scanning, briefly press the key.

To start Advanced Scanning:

1. Set the Interference Eliminator Code to "zero" or OFF.
2. Briefly press the key. The scan will appear in the display, and the radio will begin to scroll through the channels. No Interference Eliminator Codes will filter what is heard.
3. When the radio detects channel activity with ANY code (or NO code), it stops scrolling and you can hear the transmission. Any Interference Eliminator Code that may be in use by that party will be detected and displayed.
4. To respond and talk to the person transmitting, press within five seconds of the end of the transmission. The radio will transmit using the newly detected Interference Eliminator Code.
5. The radio will resume scrolling through the channels five seconds after the end of any received activity.
6. To stop scanning, briefly press the key.

Press to send a call tone. This allows your voice to pass through the Q_T noise filter on the receiving radio.

3. Press and speak normally.

Note: If you skip step 2, the beginning of your message may not be heard on the receiving radio. For a 30-second period, starting after the last transmission, all transmissions received on the selected channel and code will pass through the Q_T noise filter.

Keypad Tones

You may enable or disable the speaker key tones. You will hear the key tone each time a button is pushed.

1. Press until appears. The current setting On/Off will flash.

2. Press either or to turn On or Off.

3. Press to confirm or to continue set up.

Note: When the key tone feature is off, the following are not disabled:

- Transmit timeout alert tone
- Call tone
- Low battery alert tone or
- The transmitted talk confirmation tone

Transmitting a Talk Confirmation Tone

You can set your radio to transmit a unique tone when you finish transmitting. It is like saying "Roger" or "Over" to let others know you are finished talking.

1. With the radio on, press until the appears. The current setting On/Off flashes.

2. Press or to turn On or Off.

3. Press to set or to quit menu mode.

Special Features

Emergency Alert Mode

The Emergency Alert feature can be used to signal members in your group of your need for urgent help. MJ series radios will operate in an automatic "hands-free" emergency control mode for a total of 30 seconds after activating the Emergency Alert. MJ series radios in your group will automatically advance the speaker volume to the maximum setting and sound a warbling alert tone for 8 seconds. The alert tone is emitted from your own radio speaker and the receiving radios in your group. After the 8 second alert, any spoken words or incidental sounds at your end will be transmitted to the group for 22 seconds. For the 30 second duration of Emergency Alert mode, MJ series radio controls and buttons will be locked to maximize reception of the emergency message.

1. Press and hold the Emergency Alert button for 3 seconds.

2. Release the button after the LED Indicator glows red and the alert tone begins to sound. There is no need to continue to hold the Emergency Alert button or use PTT for your message to be transmitted.

3. After the alert tone ends you may speak into the microphone. Your voice or incidental sounds will be transmitted. The LED indicator will continue to glow for the duration of the 22 second period.

4. After 30 seconds your radio speaker will emit a Talk Confirmation Tone and the LED Indicator will extinguish. Operation then returns to normal two-way mode.

Note: All Motorola Talkabout EM, MJ, and MR series radios are fully compatible with the Emergency Alert feature. Radios other than EM, MJ, and MR series can receive the emergency alert signal, but will not respond

more quickly to any activity.

To start Scanning:

1. Briefly press the key. The scan will appear in the display, and the radio will begin to scroll through the channels and code combinations.
2. When the radio detects channel activity matching the channel and code combination, it stops scrolling and you can hear the transmission.
3. To respond and talk to the person transmitting, press within five seconds after the end of the transmission.
4. The radio will resume scrolling through the channels five seconds after the end of any received activity.
5. To stop scanning, briefly press the key.

To start Advanced Scanning:

1. Set the Interference Eliminator Code to "zero" or OFF.
2. Briefly press the key. The scan will appear in the display, and the radio will begin to scroll through the channels. No Interference Eliminator Codes will filter what is heard.
3. When the radio detects channel activity with ANY code (or NO code), it stops scrolling and you can hear the transmission. Any Interference Eliminator Code that may be in use by that party will be detected and displayed.
4. To respond and talk to the person transmitting, press within five seconds of the end of the transmission. The radio will transmit using the newly detected Interference Eliminator Code.
5. The radio will resume scrolling through the channels five seconds after the end of any received activity.
6. To stop scanning, briefly press the key.

Scanning Notes:

1. If you press while the radio is scrolling through inactive channels, the transmission will be on the "home channel". Scanning will resume five seconds after the end of your transmission. You may press the key to stop scanning at any time.
2. If the radio stops on an undesired transmission, you may immediately resume the scan by briefly pressing or .
3. If the radio repeatedly stops on an undesired transmission, you may temporarily remove that channel from the scan list by pressing and holding or for three seconds. You may remove more than one channel in this way.
4. To restore the removed channel(s) to the scan list, turn the radio off and then back on, or exit and re-enter the scanning mode by pressing .
5. You cannot remove the home channel from the scan list.
6. In Advanced Scan, the detected code will only be used for one transmission. You must note the code, exit scan, and set that detected code on that channel to permanently use the detected code.

Weather Receiver

Your radio can tune in to broadcasts by the United States National Oceanic and Atmospheric Administration (NOAA) Weather Radio and Environment Canada Weatheradio.

with adjusted volume settings, locked controls, or a warbling alert tone. Users of other radio models set to the same channel and Interference Eliminator Code will hear a steady tone for 8 seconds followed by the voice transmission for 22 seconds.

Warning: The Emergency Alert feature should only be used in the event of an actual emergency. Motorola is not responsible if there is no response to the emergency alert from the receiving group.

Built-in Flashlight

Press and hold the flashlight button to turn and keep the light on. The switch functions as a momentary control for the light.

Note: Turn off the flashlight when not in use to conserve battery power.

Keypad Lock

To avoid accidentally changing your radio settings:

1. Press and hold until displays.
2. When in lock mode, you can turn the radio on and off, adjust the volume, receive, transmit, send a call tone, and monitor channels. All other functions are locked.

To unlock the radio, press and hold until is no longer displayed.

Scanning Channels

Use scan to search the 22 channels for transmissions from unknown parties, to find someone in your group who has accidentally changed channels, or to quickly find unused channels for your own use.

There is a priority feature and 2 modes of scanning (basic and advanced) to make your search more effective. The basic scan mode uses the channel and code combinations for each of the 22 channels as you have set them (or with the default code value of 1). The "Advanced Scan" mode will scan all channels for any and all codes, detect any code in use, and use that code value temporarily for that channel.

Priority is given to the "home channel," that is, the channel (and Interference Eliminator Code) your radio is set to when you start the scan. This means the initial channel (and code setting) is scanned more often than the other 21 channels, and your radio will respond quickly to any activity occurring on the home channel as a priority.

To start Scanning:

1. Briefly press the key. The scan will appear in the display, and the radio will begin to scroll through the channel and code combinations.
2. When the radio detects channel activity matching the channel and code combination, it stops scrolling and you can hear the transmission.
3. To respond and talk to the person transmitting, press within five seconds after the end of the transmission.
4. The radio will resume scrolling through the channels five seconds after the end of any received activity.
5. To stop scanning, briefly press the key.

To start Advanced Scanning:

1. Set the Interference Eliminator Code to "zero" or OFF.
2. Briefly press the key. The scan will appear in the display, and the radio will begin to scroll through the channels. No Interference Eliminator Codes will filter what is heard.
3. When the radio detects channel activity with ANY code (or NO code), it stops scrolling and you can hear the transmission. Any Interference Eliminator Code that may be in use by that party will be detected and displayed.

To respond and talk to the person transmitting, press within five seconds of the end of the transmission. The radio will transmit using the newly detected Interference Eliminator Code. The radio will resume scrolling through the channels five

You can listen to a weather channel (see "Weather Channels and Frequencies" table below) or set your radio to alert you to emergency weather broadcasts that interrupt routine broadcasts. When you listen to a weather channel, you cannot use your radio in scan mode or for two-way communications.

Both NOAA and Environment Canada have transmitters located throughout the United States and Canada, respectively. These transmitters broadcast watches, forecasts, and other information 24 hours a day.

Note: NOAA weather radio stations are assigned to cover specific areas and service may be limited. Please check with your local weather office for frequency and details, or visit www.weather.gov/nwr in the US or www.msc.ec.gc.ca/msb/weatheradio in Canada to view the appropriate transmitter for your area.

The use of the NOAA logo does not provide an endorsement or implied endorsement by NOAA's National Weather Service, nor does the use of the Weatheradio logo provide an endorsement or implied endorsement by Environment Canada.

Turning Weather Channel Reception On and Off

1. To turn weather reception on, press and hold for 3 seconds.
2. To turn off, press or turn the radio off and then back on.

Setting the Weather Channel

Your radio receives weather frequencies:

1. After turning weather reception on, press . The current channel flashes.
2. Press or to select the appropriate channel with good reception in your area.
3. Press to save the weather channel setting.

Setting the Weather Alert

Your radio can be set to respond to NOAA Weather Radio emergency messages. A special alarm tone sounds an alert and turns on the weather receiver to give you immediate weather and emergency information.

1. After turning weather reception on, press twice. On/Off displays.
2. Press or to select On/Off. If you activate Weather Alert and return to two-way mode, will display.
3. Press to save the Weather Alert setting.
4. Press to return to two-way mode.

As with two-way radio reception, weather channel reception depends on how close you are to a transmitter and whether you are indoors or outdoors. Because weather channels are transmitted without codes, they may contain static or noise. Weather Alert will not function while actively transmitting or receiving in two-way mode.

Weather Channels and Frequencies

Weather Channel	Frequency	Weather Channel	Frequency
WX1	162.550 MHz	WX7	162.525 MHz
WX2	162.400 MHz	WX8	161.650 MHz
WX3	162.475 MHz	WX9	161.775 MHz
WX4	162.425 MHz	WX10	161.750 MHz
WX5	162.450 MHz	WX11	162.000 MHz
WX6	162.500 MHz		

Weather Channels and Frequencies

Weather Channel	Frequency	Weather Channel	Frequency
WX1	162.550 MHz	WX7	162.525 MHz
WX2	162.400 MHz	WX8	161.650 MHz
WX3	162.475 MHz	WX9	161.775 MHz
WX4	162.425 MHz	WX10	161.750 MHz
WX5	162.450 MHz	WX11	162.000 MHz
WX6	162.500 MHz		

Channels and Frequencies

Channel	Frequency	Description	Channel	Frequency	Description
1	462.5625 MHz	GMRS/FRS	12	467.6625 MHz	FRS
2	462.5875 MHz	GMRS/FRS	13	467.6875 MHz	FRS
3	462.6125 MHz	GMRS/FRS	14	467.7125 MHz	FRS
4	462.6375 MHz	GMRS/FRS	15	462.5500 MHz	GMRS
5	462.6625 MHz	GMRS/FRS	16	462.5750 MHz	GMRS
6	462.6875 MHz	GMRS/FRS	17	462.6000 MHz	GMRS
7	462.7125 MHz	GMRS/FRS	18	462.6250 MHz	GMRS
8	467.5625 MHz	FRS	19	462.6500 MHz	GMRS
9	467.5875 MHz	FRS	20	462.6750 MHz	GMRS
10	467.6125 MHz	FRS	21	462.7000 MHz	GMRS
11	467.6375 MHz	FRS	22	462.7250 MHz	GMRS